

ZT400 Technical Training

Bluetooth Connectivity Demonstration

1.) Open the **Settings App**.



2.) Select the **Bluetooth** setting.



3.) Switch Bluetooth **on**.



4.) Select your Printer's **serial number** from the list.



5.) You should see that it is now connected. Now close the app.



6.) Open the Zebra Setup Utility (ZSU) App.



7.) Now select the **Serial number button** at the bottom of the screen.



8.) Select **Choose Printer**.



9.) Select the **Serial number** of your printer.



10.) Notice your printer's serial number is identified at the bottom of the screen. Select **Files** button.



11.) Select the Desired file from the list. (Example **4x6.zpl**).



12.) Now select the **Print** button in the upper right corner of the screen.



13.) You should see 1 label print.



End of Demo