

■ Battery Status Indication



- Inactivity time out is user configurable

■ Bluetooth Status Indication



■ Error condition



- Solid red: Media cover open
- Blinking red: Out of paper