

Reset Printer Factory Defaults

Performing this resets the printer configuration to the factory default values for the non-network printer settings. Perform a sensor calibration after this procedure. (See *Manual Calibration - Media* on page 75.)

To perform a Reset Printer Factory Defaults procedure (FEED + PAUSE Self Test), complete these steps:

1. Turn off (O) the printer.
2. Press and hold **FEED + PAUSE** while turning on (I) the printer.
3. Hold **FEED + PAUSE** until the first control panel light turns off.

The printer configuration is reset to the factory default values. No labels print at the end of this test.

Reset Network Factory Defaults

Performing this procedure resets the network configuration settings only to the factory default values.

To perform a Reset Network Factory Defaults procedure (CANCEL + PAUSE Self Test), complete these steps:

1. Turn off (O) the printer.
2. Press and hold **CANCEL + PAUSE** while turning on (I) the printer.
3. Hold **CANCEL + PAUSE** until the first control panel light turns off.

The printer's network configuration is reset to the factory default values. No labels print at the end of this test.