

## ^JS – Sensor Select

**Format** ^JSa



**Note** • This command is ignored on Zebra ZM400/ZM600 and RZ400/RZ600 printers. This command is only for use with the S4M and Z Series printers (with the exception of the ZM400/ZM600/RZ400/RZ600).

Parameters	Details
a = sensor selection	<p><i>Accepted Values:</i></p> <ul style="list-style-type: none"> <li>A = auto select</li> <li>R = reflective sensor</li> <li>T = transmissive sensor</li> </ul> <p><i>Default Value:</i></p> <ul style="list-style-type: none"> <li>Z series = A</li> <li>S4M = R</li> </ul>