


Table 10 • Printer Parameters (Sheet 3 of 27)

Parameter	Action/Explanation
<div style="border: 1px solid black; padding: 5px;">           MEDIA TYPE -NON-CONTINUOUS +         </div>	<p><b>Set Media Type</b></p> <p>This parameter tells the printer the type of media that you are using (see <i>Types of Media</i> on page 35 for more information). Selecting continuous media requires that you include a label length instruction in your label format (^Lxxxxx if you are using ZPL or ZPL II).</p> <p>When non-continuous media is selected, the printer feeds media to calculate label length (the distance between two recognized registration points of the inter-label gap, webbing, or alignment notch or hole).</p> <p><b>Default:</b> NON-CONTINUOUS</p> <p><b>Selections:</b> CONTINUOUS, NON-CONTINUOUS</p> <p><b>To change the value shown:</b></p> <ol style="list-style-type: none"> <li>1. Press the left or right oval to toggle between the options.</li> </ol>
<div style="border: 1px solid black; padding: 5px;">           SENSOR TYPE -WEB +         </div>	<p><b>Set the Sensor Type</b></p> <p>This parameter tells the printer whether you are using media with a web (gap/space between labels, notch, or hole) to indicate the separations between labels or if you are using media with a black mark printed on the back. If your media does not have black marks for registration on the back, leave your printer at the default (WEB).</p> <p><b>Default:</b> WEB</p> <p><b>Selections:</b> WEB, MARK</p> <p><b>To change the value shown:</b></p> <ol style="list-style-type: none"> <li>1. Press the left or right oval to toggle between the options.</li> </ol>
<div style="border: 1px solid black; padding: 5px;">           PRINT METHOD -THERMAL-TRANS. +         </div>	<p><b>Select Print Method</b></p> <p>The print method parameter tells the printer the method of printing that you wish to use: direct thermal (no ribbon) or thermal transfer (using thermal transfer media and ribbon).</p> <p><b>Default:</b> THERMAL TRANSFER</p> <p><b>Selections:</b> THERMAL TRANSFER, DIRECT THERMAL</p> <p> <b>Note</b> • Selecting direct thermal when using thermal transfer media and ribbon creates an error condition, but printing continues.</p> <p><b>To change the value shown:</b></p> <ol style="list-style-type: none"> <li>1. Press the left or right oval to toggle between the options.</li> </ol>